


Jabra Elite 8 Active 00 - 000

000 Windows 00000 LE 000

0000

- Microsoft windows 11022H2 000000

1. 0 Windows 00000 Start0000000
2. 00 Settings > Bluetooth & devices > Devices000 > 000
00 > 0000



3. 00000 Device settings0000000000 Use LE Audio when available0000000 LE 0000000000000000